



aFe POWER Silver Bullet

Throttle Body Spacer

Part Number: 46-33023

INSTALLATION INSTRUCTIONS

Important!

Please verify the parts list and read all instruction steps before you begin installation.

Make	Model	Year	Engine
Ford	F-250	05-10	V10-6.8L
Ford	F-350	05-10	V10-6.8L

1. Remove the air duct assembly from throttle body. Disconnect the harness to throttle body.
2. Remove the four bolts from the throttle body and then remove the throttle body.
3. Inspect Silver Bullet Throttle Body Spacer. If the O-ring is not already held in the spacer, be sure to seat it fully in the recessed groove on the engraved side.
4. Reinstall the throttle body with the Silver Bullet Throttle Body Spacer (O-ring side towards throttle body) and secure it in place with the provided longer bolts and washers. Tighten the bolts to 10Nm (89lb/in).
5. Reconnect the throttle body harness and reinstall the air duct assembly to the throttle body.
6. Your installation is now complete.



Parts List

- 1 Silver Bullet Spacer
- 4 6mm x 50mm screws
- 4 6mm flat washers
- 1 O-ring (installed on spacer)

advanced FLOW engineering, inc.

252 Granite Street, Corona, CA 92879

Main Line: 951-493-7100 Tech Support: 951-493-7185

www.aFePower.com

Last Updated: 08/06/2020
ZS