



INSTALLATION INSTRUCTIONS

MAKE: Jeep
MODEL: Wrangler (JL)
YEAR: 2018 - 2020
ENGINE: V6-3.6L (2DR)

ROCK BASHER
3" Cat-Back Exhaust
49-48074



Caution: aFe recommends professional installation on our products. Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation.

Step 1: **(Read instructions prior to installation).** It may be helpful to lubricate all the factory isolation rubber mounts, before taking off stock exhaust and also before installing aFe exhaust. Always use a jack or stand for support when installing or uninstalling any exhaust system.

Step 2: Begin by removing your stock exhaust from the rear of your truck working your way forward. Remove the factory muffler assembly and mid-pipe/resonator. Take caution not to damage the factory isolation mounts as they will be reused.

NOTE: It may be easier to unbolt the muffler hanger brackets from the frame than to disconnect the factory isolation mounts.

Step 3: Remove the factory ball clamp from the mid-pipe/resonator.

Step 4: Place the factory ball clamp removed in **Step 3** onto the muffler assembly.

Step 5: Install the muffler assembly onto the factory y-pipe and slip hanger into the factory isolation mount.

Step 6: Straighten exhaust and tighten down ball clamp.

Step 7: Double check all work and ensure everything is tight. Congratulations, your system is now complete and full.

Step 8: It is recommended to re-tighten all clamps and bolts after 50-100 miles.