



INSTALLATION INSTRUCTIONS

MAKE: Dodge
MODEL: Charger
YEAR: 2015 - 2020
ENGINE: V8-6.2L / 6.4L

Exhaust Tip Set

49C32068-C
49C32068-B
49C32068-P



Tip Assembly

05-145672 (Carbon)
05-145672B (Black)
05-145672P (Polished)

Tip Assembly

05-145672 (Carbon)
05-145672B (Black)
05-145672P (Polished)

Caution: aFe recommends professional installation on our products. Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation.

- Step 1:** **(Read instructions prior to installation.)** For faster removal and installation of exhaust a trained professional is recommended for this procedure.
- Step 2:** Secure the vehicle on jack/stands refer to your owner's manual for specified jack stand locations.
- Step 3:** Loosen the bolt on the left OE exhaust tip clamp and slide the OE tip off the exhaust system.
- Step 4:** Loosen the bolt on the right OE exhaust tip clamp and slide the OE tip off the exhaust system.
- Step 5:** Slip the right-side exhaust tip onto the right side exhaust outlet.
- Step 6:** Align/center the right-side exhaust tip in the rear fascia and tighten the bolt on the exhaust tip clamp.
- Step 7:** Slip the left-side exhaust tip onto the left side exhaust outlet.
- Step 8:** Align/center the left-side exhaust tip in the rear fascia and tighten the bolt on the exhaust tip clamp.
- Step 9:** Adjust the exhaust tips for best alignment and tighten the exhaust bolt clamps.
- Step 10:** Remove the vehicle from the jack stands.
- Step 11:** Your installation is now complete.
- Step 12:** It is recommended to re-tighten all clamps and bolts after 50-100 miles.