



GrimmSpeed Install Guide Series
08-14 Subaru WRX/STI Fender Shrouds
Updated 12/15/2020



Introduction:

This guide will walk you through the install steps for The 08-14 Subaru WRX and STI Fender Shrouds.

Notes:

This install was done on a 2010 Subaru STI. It is an easy install and should take around 15-20 minutes. This kit does not include any extra hardware. You will reuse your OEM fender bolts.

Tools Needed:

- 10mm Socket and Wrench

If you have any questions don't hesitate to contact us directly via phone or email:

support@grimmspeed.com | 612-379-0000

1. Locate the two upper 10mm fender bolts. Remove the two bolts from the top of the fender and place them aside.



2. Slide the GrimmSpeed Fender Shroud between the fender and the support bracket underneath. Align the holes and reinstall the two 10mm bolts.



3. Repeat steps 1-2 on opposite side. Enjoy your new GrimmSpeed Fender Shrouds!

