



**ADJ. SOLID SUBFRAME BUSHING KIT  
INSTALLATION INSTRUCTIONS:**

**09-UP NISSAN 370Z Z34**

**PART NUMBER:**

**SBNS-0400**

We recommend that installation of all Voodoo13 parts be completed by a professional who is experienced in suspension tuning. With proper installation and maintenance, Voodoo13 suspension products will provide exceptional performance and durability. For any questions, please contact Voodoo13 immediately. We thank you for choosing Voodoo13 for your suspension tuning needs!

### **NEED HELP?**

Our representatives are here to help you with any questions concerning the operation of this product.

**CALL 480-889-0812**

Monday thru Friday 8:30am to 5:30pm MST

### **RECOMMENDED TOOLS AND SUPPLIES**

- General Mechanics Tool Set
- Vehicle Jack and Safety Jack Stands (Or Vehicle Lift)
- Torque Wrench

### **PART BREAKDOWN**

NOTE: For any OE hardware please refer to OEM service manual for torque specifications. For all included hardware, please torque to specifications shown below. It is recommended to use a torque wrench when tightening instead of an impact gun and apply anti-seize on all threads.

## INSTALLATION PROCEDURE

**Step 1:** Remove subframe from vehicle per your service manual.

**Step 2:** Remove old subframe bushings. Prepare yourself and be patient, these can be very difficult and timely to remove. Cut the rubber liners out with a Sawzall or hand saw. Cut the steel liner until the housing can be collapsed in on itself and pushed out. Take care not to damage the aluminum subframe during this process. Your friends may advise you to just burn them out, but this should not be done on aluminum sub frames, like the 370z. The temper in the aluminum can be weakened.

**Step 3:** Press in new bushings into the subframe. Be sure that the bushing is concentric with the hole while pressing the bushing in. If the bushing is not being pressed in straight, damage to the parts or your subframe may result. Be sure that all bushings are seated firmly in place before reinstalling your subframe. It is possible to hammer them into place, but it is not advised. Extra care must be taken to ensure proper alignment with the bushing and the housing.

The parts have been packaged and marked.

FU = Front Upper Bushing

FL = Front Lower Bushing

RU = Rear Upper Bushing

RL = Rear Lower Bushing

# WARRANTY

All products sold are subject to the following warranty:

Voodoo13 offers a Limited Lifetime Warranty for our products to the original retail consumer against defects and workmanship when used on light truck and car applications under normal operating conditions. This warranty does not apply to parts that have been improperly installed or wearable items such as, but not limited to, worn bushings or bearings unless proven to be defective from the manufacturer.

Exterior finish on all Voodoo13 products is not considered a valid warranty; consumers are responsible for the maintenance of paint, anodize or raw metal finish.

The consumer will be responsible for the removal and freight costs both to and from the Distributor from which the product was originally purchased. Proof of purchase and product registration through the Voodoo13 website is mandatory in order to receive warrantee replacement; original invoice from the Distributor from which the product was purchased must accompany the product in question for warrantee.

Voodoo13 has the right to refuse a warrantee claim if procedures are not met by the original consumer. All returns must have an R.M.A. approval from Voodoo13 prior to shipping direct to the Voodoo13 facility. Exclusions from this warranty are sales outside of the United States, the finish, dents, rust, or any condition caused by abnormal use or neglect.

## WARNING

High performance parts. For off-road use only. Installation should be carried out by a qualified facility. Improper use or installation may result in injury or death.



**VOODOO13**  
254 W Broadway Rd  
Mesa, AZ 85210  
Ph: 480.889.0812  
Fax: 480.829.8103  
[www.VOODOO13USA.com](http://www.VOODOO13USA.com)