

**99-06 Chevy Duramax Edge Attitude Mount:**

1. Attach the two Velcro pieces together. Peel back strip to expose adhesive from one side and attach to the recessed area of the mount where the Attitude fits.
2. Expose adhesive and install Attitude in mount. Press firmly to engage adhesive to back of Display (**Do not press on LCD**).
3. Run wires between mount and pillar (extra space has been provided for wires).
4. With the new pillar installed over the stock pillar, drill  $\frac{3}{16}$ " holes through both.
5. Press in Ratchet Fasteners to hold pillars together.

**99-02 Ford Super Duty Edge Attitude Mount:**

1. Attach the two Velcro pieces together. Peel back strip to expose adhesive from one side and attach to the recessed area of the mount where the Attitude fits.
2. Expose adhesive and install Attitude in mount. Press firmly to engage adhesive to back of Display (**Do not press on LCD**).
3. Run wires between mount and pillar (extra space has been provided for wires).
4. Place mount on A-pillar in final position.
5. Along the top of the mount, drill a  $\frac{3}{16}$ " hole through the mount and A-pillar.
6. Press in Ratchet Fasteners.

**03-06 Ford Super Duty Edge Attitude Mount:**

1. Attach the two Velcro pieces together. Peel back strip to expose adhesive from one side and attach to the recessed area of the mount where the Attitude fits.
2. Expose adhesive and install Attitude in mount. Press firmly to engage adhesive to back of Display (**Do not press on LCD**).
3. Remove Handle from A-pillar (8mm bolts).
4. Run wires between mount and pillar (extra space has been provided for wires).
5. Place mount on pillar.
6. Reinstall handle (The handle will catch the top edge of mount, holding it in place).

**03+ Dodge Ram Edge Attitude Mount:**

1. Attach the two Velcro pieces together. Peel back strip from one side and attach to the recessed area of the mount where the Attitude fits.
2. Install Attitude in pod, press firmly to engage adhesive to back of Display (**Do not press on LCD**).
3. Run wires between mount and the stock A-pillar (there is a visible channel molded in for the wire).
4. Remove the lower cap and screw from the stock A-pillar handle.
5. Place mount over the stock A-pillar.
6. Use provided (longer) screw to secure mount and A-pillar.

**98-02 Dodge Ram (w & w/o Speaker) Edge Attitude Mount:**

1. Your new A-pillar mount installs over the factory A-pillar. It is not a replacement.
2. Remove the stock A-pillar
3. For models with the Infinity speaker, remove speaker from A-pillar. Cut or grind down the raised speaker hole on the stock A-pillar to allow the mounting of the new A-pillar mount.
4. Another option is to purchase and install the base model (without speaker) A-pillar from your local Dodge dealer. This will save the extensive modification made to the original speaker A-pillar.
5. Hold the A-pillar mount in position on the factory A-pillar. Slight trimming of the A-pillar mount may be required for a perfect fit in some applications. Drill  $\frac{3}{16}$ " holes through the 4 corners of both the mount and factory A-pillar.
6. Attach the two pieces of Velcro together. Peel back from one side and attach to the recessed area of the mount where the Attitude fits.
7. Install Attitude in pod, press firmly to engage adhesive to back of display (don't press on LCD). Install speaker in A-pillar cover. No retaining hardware is needed to hold speaker because it snaps in place.
8. The mount has clearance for the Attitude wires to be run down the back and through the bottom. Secure wiring to the back of the new mount.
9. Insert ratchet fasteners through holes to attach mount to factory A-pillar. Re-install mount/factory A-pillar assembly, making sure wires are not pinched.
10. The mount has clearance for the Attitude wires to be run down the back and through the bottom. Secure wiring to the back of the new mount.

**Auto Meter Gauge Works Three Year Limited Warranty**

Gauge Works warrants to the consumer that all Auto Meter Gauge Works products will be free from defects in material and workmanship. Products that fail will be repaired or replaced at Auto Meter Gauge Works' option to the consumer, when determined by Auto Meter Gauge Works that the product failed due to defects in material or workmanship. This warranty is limited to the repair or replacement of parts in the Auto Meter Gauge Works Product and the necessary labor done by Auto Meter Gauge Works to effect the repair or replacement of the Auto Meter Gauge Works product. In no event shall this warranty exceed the original purchase price of the Auto Meter Gauge Works product nor shall Auto Meter Gauge Works be responsible for special, incidental or consequential damages or costs incurred due to the failure of this product. Warranty claims to Auto Meter Gauge Works must be transportation prepaid and accompanied with proof of purchase. This warranty applies only to the original purchaser of product and is non-transferable. Improper use or installation, accident, water damage, abuse, unauthorized repairs or alterations voids this warranty. Auto Meter Gauge Works disclaims any liability for consequential damages due to breach of any written or implied warranty on all products manufactured by Auto Meter Gauge Works. This warranty is made solely by Gauge Works with Auto Meter being the agent to contact for warranty claims. If the partnership between Auto Meter and Gauge Works dissolves, then all warranty adjustments will be covered by the Gauge Works Co.